

## Fuel Dispatch

### A Coordinator-Provided Service

#### SAMPLE: low fuel warning screen

**Asset View Report**  
The following represents the most recent activity of the selected asset.


---

**Recent Activity**


**Report Name** Foods Display  
**Genset** Foods  
**Last Updated** 8/6/2003 6:39:07 PM

---

**Analog Values**



**Main Fuel Tank Level**  
567.2 gal




**System Battery Voltage**

---

**Discrete Values**

<b>Run Status</b>	<input checked="" type="radio"/>	Not Running
<b>Low Fuel Level</b>	<input checked="" type="radio"/>	Low Fuel Alarm
<b>ATS in Emergency Position</b>	<input type="radio"/>	No
<b>ATS in Normal Position</b>	<input type="radio"/>	No
<b>Battery Charger Failure</b>	<input type="radio"/>	OK
<b>Coolant Loss/Shutdown</b>	<input type="radio"/>	OK
<b>Diagnostic Code Shutdown</b>	<input type="radio"/>	OK
<b>Emergency Stop</b>	<input type="radio"/>	OK
<b>Emergency Stop Shutdown</b>	<input type="radio"/>	OK
<b>High Coolant Temperature Shutdown</b>	<input type="radio"/>	OK
<b>Low Oil Pressure</b>	<input type="radio"/>	OK

PointGuard Coordinator



The Fuel Dispatch service option gives you the ability to send a fuel truck to your site, in response to a fuel level alarm or by simply contacting PointGuard Operations with your request.

The PointGuard Coordinator follows your predefined procedures for dispatching your fuel vendor, per the terms of your contract. The Coordinator assists the fuel vendor by providing essential site information such as fuel needed, location name, address and contact person.

Our trained Coordinators are there for you 24/7/365, ready to dispatch fuel vendors and keep your gensets running when you need them!

This service option includes one tank system per site. Additional charges may apply for multiple tank systems. This service is included in the Premium Alarm Response option.